


BAIT CASTING REEL

CATFISH COLLECTOR SERIES

CS200



Key No.

Parts No.

Parts name

1	2E2-080-01	A30M-040 SCREW
2	2F5-050-03	HANDLE NUT CAP
3	2E3-068-01	HANDLE NUT
4	2YH-270-07	HANDLE TOTAL ASSEMBLY
5	2W2-058-01	KEY WASH
6	2E4-018-01	RETAINER
7	2F8-050-01	CLICK LEAF SPRING HOLDER
8	2L3-029-01	CLICK LEAF SPRING
9	2D4-008-03	STAR DRAG LEVER
10	2Q1-052-01	STAR DRAG SPRING
11	2E3-029-01	STAR DRAG NUT
12	2W1-020-01	081-130 WASHER
13	2L1-004-01	SPRING WASHER
14	2W1-035-05	080-105 WASHER
15	2Z1-024-05	812-2.5 BALL BEARING
16	2A4-022-01	ONE-WAY CLUTCH INNER TUBE
17	2E3-024-01	CAST CONTROL NUT
18	2W5-026-01	SPACER
19	2W5-029-01	CAST CONTROL SPACER
20	2E4-019-01	BEARING RETAINER
21	2Z1-001-05	508-2.5 BALL BEARING
22	2E9-005-01	O RING
23	2E0-011-01	RIGHT SIDE COVER SCREW
24	2W1-132-01	036-060 WASHER
25	2YF-033-26	RIGHT SIDE COVER ASSEMBLY
26	2E5-006-01	E2.5 RETAINER
27	2Q1-056-01	RIGHT SIDE COVER SCREW SPRING
28	2YZ-007-01	ONE-WAY CLUTCH BEARING ASSEMBLY
29	2W2-032-01	KEY WASHER
30	2W1-126-01	082-210 WASHER
31	2W3-017-01	EARED WASHER
32	2W1-111-01	100-230 WASHER
33	2W2-025-01	KEY WASHER
34	2G1-027-01	DRIVE GEAR
35	2YG-023-01	OSCILLATING GEAR ASSEMBLY
36	2A3-027-01	RATCHET
37	2M3-053-01	DRIVE SHAFT
38	2Z1-018-05	510-3 BALL BEARING
39	2G2-010-01	PINION GEAR
40	2Q1-031-01	YOKE SPRING
41	2A2-039-01	PINION YOKE
42	2E2-047-01	A20M-065 SCREW
43	2F8-030-01	CLUTCH CAM RETAINER
44	2YA-035-01	CLUTCH CAM ASSEMBLY

Key No.

Parts No.

Parts name

45	2Z1-010-05	812-3.5 BALL BEARING
46	2M2-003-01	CLUTCH PLATE
47	2Q3-086-01	RETRACTOR SPRING
48	2F8-039-01	GEAR SETTING PLATE
49	2E2-005-03	B26M-080 SCREW
50	2W1-054-01	052-080 WASHER
51	2W1-070-01	052-080 WASHER
52	2E5-013-01	E3.0 RETAINER
53	2YS-083-09	SPOOL ASSEMBLY
54	2C2-057-01	BRAKE COLLAR
55	2Z1-023-01	814-4 BALL BEARING
56	2F3-041-01	CLICK GEAR
57	2W1-046-01	051-068 WASHER
58	2C2-042-01	WORM SHAFT BUSH
59	2C4-010-01	LEVEL WIND GUARD
60	2YR-038-01	LINE GUIDE ASSEMBLY
61	2MS-005-01	LINE GUIDE PIN
62	2W1-100-01	020-068 WASHER
63	2E3-014-01	LINE GUIDE NUT
64	2E2-034-01	A20M-090 SCREW
65	2YB-095-14	BODY ASSEMBLY
66	2YM-042-01	WORM SHAFT ASSEMBLY
67	2E2-003-01	B26M-036 SCREW
68	2P4-006-03	LEVEL WIND GUIDE
69	2G3-015-01	IDLE GEAR
70	2W1-166-02	031-102 WASHER
71	2E2-007-01	B30M-100 SCREW
72	2C4-013-02	CASTING BAR GUIDE A
73	2YS-085-03	CASTING BAR ASSEMBLY
74	2C4-014-02	CASTING BAR GUIDE B
75	2P2-021-01	CASTING BAR PIN
76	2P4-008-03	CASTING BAR SUPPORT
77	2E4-011-01	BEARING RETAINER
78	2W5-015-01	CAST CONTROL SPACER
79	2F6-032-02	CLICK PLATE
80	2E2-022-01	B20M-030 SCREW
81	2F5-108-17	LEFT SIDE COVER
82	2X3-004-02	WRENCH
83	2YT-143-09	SPOOL TOTAL ASSEMBLY
84	2F2-020-01	CLICK SPRING
85	2F4-018-01	CLICK PAWL
86	2F7-004-01	CLICK SWITCH
87	2E5-020-01	E1.5 RETAINER