



Key NO.	Parts No.	Parts name	Key NO.	Parts No.	Parts name
1	2YD-030-15	DRAG KNOB ASSEMBLY	49	2Q3-009-01	ANTI-REVERSE SPRING
2	2E9-028-01	WATER PROOF RING	50	2A1-026-17	ANTI-REVERSE LEVER
3	2E4-028-01	DRAG WASHER RETAINER	51	2E2-013-04	B20M-060 SCREW
4	2W3-013-01	EARED WASHER	52	2G3-071-01	OSCILLATING GEAR
5	2W2-027-02	KEY WASHER	53	2M2-012-01	OSCILLATING CAM
6	2W1-094-01	060-220 WASHER	54	2M1-056-01	OSCILLATING SLIDER
7	2YT-363-03	SPOOL TOTAL ASSEMBLY	55	2E5-049-01	OSCILLATING SLIDER RETAINER
8	2W2-011-01	KEY WASHER	56	2E2-040-01	b26M-060 SCREW
9	2L3-015-01	CLICK LEAF SPRING	57	2L2-014-01	HIT AND RUN CLICK PAWL
10	2F8-019-01	CLICK LEAF SPRING HOLDER	58	2E1-050-01	A20-060 SCREW
11	2W2-019-01	KEY WASHER	59	2Z1-035-05	917-5 BALL BEARING
12	2E3-003-01	ROTOR NUT	60	2G1-107-01	DRIVE GEAR
13	2M3-119-01	MAIN SHAFT	61	2W1-014-00	091-130 WASHER
14	2E1-019-01	D26-060 SCREW	62	2L3-033-01	CLICK LEAF SPRING
15	2R1-123-03	ROTOR	63	2Q1-091-01	CLUTCH PAWL SPRING
16	2Q3-108-01	BAIL SPRING	64	2F6-108-01	CLUTCH PAWL
17	2R5-144-01	BAIL TRIP LEVER	65	2F6-109-01	CLUTCH PAWL RETAINER
18	2R5-143-01	BAIL PAWL	66	2Q3-078-01	CLUTCH PAWL SPRING
19	2R4-161-02	BAIL TRIP COVER	67	2YA-029-01	HIT AND RUN LEVER SHAFT ASSEMBLY
20	2E1-016-04	B26-080 SCREW	68	2Q3-110-01	SPRING B
21	2E2-007-04	B30M-100 SCREW	69	2W1-180-01	112-190 WASHER
22	2R2-056-03	BAIL ARM	70	2A3-032-01	CLUTCH RATCHET
23	2C1-049-01	LINE ROLLER COLLAR	71	2F3-054-01	CLICK GEAR
24	2Z1-001-05	508-2.5 BALL BEARING	72	2W1-121-02	070-204 WASHER
25	2R6-018-02	LINE ROLLER	73	2W3-019-01	EARED WASHER
26	2C1-068-01	COLLAR	74	2Q1-002-01	DRAG SPRING
27	2YL-131-03	BAIL ASSEMBLY	75	2D3-023-01	PRESSURE SCREW
28	2E1-010-04	b30-100 SCREW	76	2D2-011-01	HIT AND RUN CONTROL NUT
29	2R5-135-01	BAIL TRIP SHAFT	77	2E5-047-01	CONTROL NUT RETAINER
30	2W1-199-01	015-027 WASHER	78	2B2-089-03	BODY COVER
31	2Q1-101-01	BAIL SPRING	79	2E1-006-04	A30-130 SCREW
32	2C2-111-01	BAIL SPRING GUIDE	80	2YH-278-03	HANDLE TOTAL ASSEMBLY
33	2R4-162-02	BAIL SPRING COVER	81	2C3-047-01	HANDLE SCREW SLEEVE
34	2A4-019-01	ONE-WAY CLUTCH INNER TUBE	82	2H6-002-01	HANDLE SCREW CAP
35	2F5-332-01	ROLLER CLUTCH RETAINER	83	2E8-004-01	STARWASHER
36	2E1-015-02	B26-060 SCREW	84	2E2-039-01	A26M-120 SCREW
37	2Q1-071-01	CAGE SPRING	85	2W1-127-01	027-048 WASHER
38	2YZ-015-01	ONE-WAY CLUTCH BEARING ASSEMBLY	86	2D4-005-03	HIT AND RUN LEVER ARM (L)
43	2F5-260-01	BEARING RETAINER	87	2C3-026-03	LEVER ARM SPACER
44	2E1-068-01	F30-100 SCREW	88	2D4-006-03	HIT AND RUN LEVER ARM (R)
45	2Z1-008-05	1020-5 BALL BEARING	89	2F5-333-03	REAR COVER
46	2G2-082-01	PINION GEAR	90	2D1-053-05	HIT AND RUN CONTROL KNOB
47	2YB-205-03	BODY ASSEMBLY	91	2E0-016-04	HIT AND RUN CONTROL KNOB SCREW
48	2A2-071-01	ANTI-REVERSE CAM	92	2E1-010-01	b30-100 SCREW