


SPINNING REEL

CAMBRIA

Please order by parts number, not key number
 Bitte, Best.-Nr. angeben (Nicht "key" -nr.)
 Veuillez indiquer le numero de la pièce (Non "key" no.)

LZ2000 / LZ2500




Key NO.	Parts No.	Parts name	Key NO.	Parts No.	Parts name
1	2YD-094-06	DRAG KNOB ASSEMBLY	30	2F5-403-01	ROLLER CLUTCH RETAINER
2	2E4-034-01	DRAG WASHER RETAINER	31	2Q2-021-01	SPRING
3	2W2-071-01	KEY WASHER	32	2YZ-022-01	ONE-WAY CLUTCH BEARING
4	2W1-226-01	080-260 WASHER	33	2A4-072-01	ONE-WAY CLUTCH INNER TUBE
5	2YT-409-06	SPOOL TOTAL ASSEMBLY	34	2Z1-003-07	714-5 BALL BEARING
6	2W2-016-01	KEY WASHER	35	2G2-148-01	PINION GEAR
7	2Z1-029-07	408-3 BALL BEARING	36	2E1-037-01	B30-080 SCREW
8	2W1-060-03	041-065 WASHER	37	2B1-157-05	BODY
9	2W1-236-01	055-188 WASHER	38	2Z1-009-07	711-3 BALL BEARING
10	2L3-014-01	CLICK LEAF SPRING	39	2G1-139-01	DRIVE GEAR
11	2M3-133-01	MAIN SHAFT	40	2W1-035-00	080-105 WASHER
12	2F8-013-01	CLICK LEAF SPRING HOLDER	41	2Z1-023-07	814-4 BALL BEARING
13	2W2-015-01	KEY WASHER	42	2M2-018-01	OSCILLATING CAM
14	2E3-007-01	ROTOR NUT	43	2G3-084-01	OSCILLATING GEAR
15	2E1-036-01	B26-040 SCREW	44	2M1-067-01	OSCILLATING SLIDER
16	2R1-134-06	ROTOR	45	2E2-030-02	F20M-050 SCREW
17	2R4-178-01	BAIL TRIP COVER	46	2B2-112-06	BODY COVER
18	2E1-020-02	B22-055 SCREW	47	2E1-055-01	A26-100 SCREW
19	2E2-094-01	B30M-090 SCREW	48	2YH-419-01	HANDLE TOTAL ASSEMBLY
20	2R2-061-06	BAIL ARM	49	2C3-042-01	HANDLE SCREW SLEEVE
21	2E1-025-01	b30-080 SCREW	50	2H6-001-13	HANDLE SCREW CAP
22	2C1-034-01	LINE ROLLER COLLAR	51	2A2-094-06	ANTI-REVERSE CAM
23	2Z1-012-07	407-2.5 BALL BEARING	52	2L5-010-01	ANTI-REVERSE CAM SPRING
24	2R6-020-02	LINE ROLLER	53	2F5-474-01	REAR COVER
25	2YL-144-06	BAIL ASSMBLY	54	2E1-020-02	B22-055 SCREW
26	2Q1-051-02	BAIL SPRING	55	2W1-260-01	120-169 WASHER
27	2R5-161-01	BAIL TRIP LEVER	LZ2500	SPECIAL PARTS	
28	2R4-179-01	BAIL SPRING COVER	5	2YT-442-06	SPOOL TOTAL ASSEMBLY
29	2E1-050-01	A20-060 SCREW			



SPINNING REEL

CAMBRIA LZ2050 / LZ2550

Please order by parts number, not key number
 Bitte, Best-Nr. angeben (Nicht "key" -nr.)
 Veuillez indiquer le numero de la piece (Non "key" no.)



Key NO.	Parts No.	Parts name
1	2YT-461-06	SPOOL TOTAL ASSEMBLY
2	2E3-007-01	ROTOR NUT
3	2YM-101-01	MAIN SHAFT ASSEMBLY
4	2E1-025-01	b30-080 SCREW
5	2YL-144-06	BAIL ASSMBLY
6	2Z1-012-07	407-2.5 BALL BEARING
7	2R6-020-02	LINE ROLLER
8	2W1-258-01	030-060 WASHER
9	2R2-061-06	BAIL ARM
10	2E2-094-01	B30M-090 SCREW
11	2Q1-051-02	BAIL SPRING
12	2R5-161-01	BAIL TRIP LEVER
13	2R4-179-01	BAIL SPRING COVER
14	2E1-020-02	B22-055 SCREW
15	2E1-036-01	B26-040 SCREW
16	2R4-178-01	BAIL TRIP COVER
17	2R1-134-06	ROTOR
18	2Q2-021-01	SPRING
19	2E1-050-01	A20-060 SCREW
20	2F5-403-01	ROLLER CLUTCH RETAINER
21	2YZ-022-01	ONE-WAY CLUTCH BEARING
22	2W1-260-01	120-169 WASHER
23	2A4-072-01	ONE-WAY CLUTCH INNER TUBE
24	2Z1-003-07	714-5 BALL BEARING
25	2G2-148-01	PINION GEAR
26	2Z1-009-07	711-3 BALL BEARING
27	2G1-139-01	DRIVE GEAR
28	2W1-035-02	080-105 WASHER
29	2Z1-023-07	814-4 BALL BEARING


Key NO.	Parts No.	Parts name
30	2YC-115-04	BODY COVER ASSEMBLY
31	2E1-055-01	A26-100 SCREW
32	2M2-018-01	OSCILLATING CAM
33	2G3-084-01	OSCILLATING GEAR
34	2M1-077-01	OSCILLATING SLIDER
35	2E5-065-01	OSCILLATING SLIDER RETAINER
36	2E2-050-01	A20M-035 SCREW
37	2YH-418-01	HANDLE TOTAL ASSEMBLY
38	2E1-037-01	B30-080 SCREW
39	2C3-042-01	HANDLE SCREW SLEEVE
40	2H6-001-13	HANDLE SCREW CAP
41	2B1-182-05	BODY
42	2F5-448-01	REAR COVER
43	2W1-149-01	062-110 WASHER
44	2E1-032-01	A20-050 SCREW
45	2F3-039-01	STAR DRAG CLICK PLATE
46	2W1-165-02	062-138 WASHER
47	2W3-024-01	EARED WASHER
48	2L1-008-01	SPRING WASHER
49	2D3-036-01	DRAG COLLAR
50	2L3-053-01	CLICK LEAF SPRING
51	2D1-078-06	DRAG KNOB
52	2E0-059-01	DRAG KNOB SCREW
53	2A2-109-06	ANTI-REVERSE CAM
54	2L5-010-01	ANTI-REVERSE CAM SPRING
LZ2550	SPECIAL PARTS	
1	2YT-462-06	SPOOL TOTAL ASSEMBLY



SPINNING REEL

CAMBRIA

LZ3000 / LZ3500




Key NO.	Parts No.	Parts name	Key NO.	Parts No.	Parts name
1	2YD-094-06	DRAG KNOB ASSEMBLY	30	2E1-050-01	A20-060 SCREW
2	2E4-034-01	DRAG WASHER RETAINER	31	2F5-436-01	ROLLER CLUTCH RETAINER
3	2W2-071-01	KEY WASHER	32	2Q2-021-01	SPRING
4	2W1-226-01	080-260 WASHER	33	2YZ-027-01	ONE-WAY CLUTCH BEARING ASSEMBLY
5	2W3-035-01	EARED WASHER	34	2A4-082-01	ONE-WAY CLUTCH INNER TUBE
6	2YT-443-06	SPOOL TOTAL ASSEMBLY	35	2Z1-005-07	816-5 BALL BEARING
7	2W2-016-01	KEY WASHER	36	2G2-165-01	PINION GEAR
8	2Z1-029-07	408-3 BALL BEARING	37	2E1-051-01	D30-080 SCREW
9	2C1-119-01	SPACER	38	2B1-173-05	BODY
10	2W1-237-01	070-225 WASHER	39	2Z1-009-07	711-3 BALL BEARING
11	2L3-015-01	CLICK LEAF SPRING	40	2G1-150-01	DRIVE GEAR
12	2M3-151-01	MAIN SHAFT	41	2W1-019-01	071-103 WASHER
13	2F8-019-02	CLICK LEAF SPRING HOLDER	42	2Z1-023-07	814-4 BALL BEARING
14	2W2-015-01	KEY WASHER	43	2M2-016-01	OSCILLATING CAM
15	2E3-002-01	ROTOR NUT	44	2G3-081-01	OSCILLATING GEAR
16	2E1-036-01	B26-040 SCREW	45	2M1-074-01	OSCILLATING SLIDER
17	2R1-146-06	ROTOR	46	2E2-009-01	F23M-060 SCREW
18	2R4-203-01	BAIL TRIP COVER	47	2B2-126-06	BODY COVER
19	2E1-065-01	B22-065 SCREW	48	2E1-055-01	A26-100 SCREW
20	2E2-094-01	B30M-090 SCREW	49	2YH-399-01	HANDLE TOTAL ASSEMBLY
21	2R2-070-06	BAIL ARM	50	2C3-042-01	HANDLE SCREW SLEEVE
22	2E1-010-01	b30-100 SCREW	51	2H6-001-13	HANDLE SCREW CAP
23	2W1-258-01	030-060 WASHER	52	2A2-106-06	ANTI-REVERSE CAM
24	2Z1-012-07	407-2.5 BALL BEARING	53	2L5-010-01	ANTI-REVERSE CAM SPRING
25	2R6-020-02	LINE ROLLER	54	2F5-475-01	REAR COVER
26	2YL-158-06	BAIL ASSEMBLY	55	2E1-070-02	B22-055 SCREW
27	2Q1-051-02	BAIL SPRING	LZ3500	SPECIAL PARTS	
28	2R5-179-01	BAIL TRIP LEVER	6	2YT-459-06	SPOOL TOTAL ASSEMBLY
29	2R4-202-01	BAIL SPRING COVER			



SPINNING REEL


CAMBRIA LZ3050 / LZ3550



Key NO.	Parts No.	Parts name	Key NO.	Parts No.	Parts name
1	2YT-463-06	SPOOL TOTAL ASSEMBLY	31	2W1-039-02	081-135 WASHER
2	2YM-102-01	MAIN SHAFT ASSEMBLY	32	2F3-004-01	CLICK GEAR
3	2E3-002-01	ROTOR NUT	33	2W1-176-01	082-168 WASHER
4	2R1-146-06	ROTOR	34	2W3-001-02	EARED WASHER
5	2E1-065-01	B22-065 SCREW	35	2W2-008-01	KEY WASHER
6	2R4-203-01	BAIL TRIP COVER	36	2L1-003-02	SPRING WASHER
7	2Q1-051-02	BAIL SPRING	37	2D3-037-01	DRAG COLLAR
8	2E1-036-01	B26-040 SCREW	38	2L3-054-01	CLICK LEAF SPRING
9	2R5-179-01	BAIL TRIP LEVER	39	2D1-079-06	DRAG KNOB
10	2R4-202-01	BAIL SPRING COVER	40	2E0-060-01	DRAG KNOB SCREW
11	2E1-010-01	b30-100 SCREW	41	2A2-110-06	ANTI-SEVERSE CAM
12	2YL-158-06	BAIL ASSEMBLY	42	2L5-010-01	ANTI-REVERSE CAM SPRING
13	2Z1-012-07	407-2.5 BALL BEARING	43	2E1-032-01	A20-050 SCREW
14	2R6-020-02	LINE ROLLER	44	2M2-016-01	OSCILLATING CAM
15	2W1-258-01	030-060 WASHER	45	2G3-081-01	OSCILLATING GEAR
16	2R2-070-06	BAIL ARM	46	2M1-078-01	OSCILLATING SLIDER
17	2E2-094-01	B30M-090 SCREW	47	2E5-066-01	OSCILLATING SLIDER RETAINER
18	2F5-436-01	ROLLER CLUTCH RETAINER	48	2E2-050-01	A20M-035 SCREW
19	2E1-050-01	A20-060 SCREW	49	2Z1-009-07	711-3 BALL BEARING
20	2YZ-027-01	ONE-WAY CLUTCH BEARING ASSEMBLY	50	2G1-150-01	DRIVE GEAR
21	2W1-268-01	130-215 WASHER	51	2W1-035-02	080-105 WASHER
22	2Q2-021-01	SPRING	52	2Z1-023-07	814-4 BALL BEARING
23	2A4-082-01	ONE-WAY CLUTCH INNER TUBE	53	2YC-116-04	BODY COVER ASSEMBLY
24	2G2-165-01	PINION GEAR	54	2E1-055-01	A26-100 SCREW
25	2Z1-005-07	816-5 BALL BEARING	55	2YH-399-01	HANDLE TOTAL ASSEMBLY
26	2E1-051-01	D30-080 SCREW	LZ3550	SPECIAL PARTS	
27	2B1-186-05	BODY	1	2YT-465-06	SPOOL TOTAL ASSEMBLY
28	2C3-042-01	HANDLE SCREW SLEEVE			

SPINNING REEL CAMBRIA LZ4000 / LZ5000

Please order by parts number, not key number
 Bitte, Best.-Nr. angeben (Nicht "key" -nr.)
 Veuillez indiquer le numero de la piece (Non "key" no.)



Key NO.	Parts No.	Parts name	Key NO.	Parts No.	Parts name
1	2YD-100-06	DRAG KNOB ASSEMBLY	28	2E1-050-01	A20-060 SCREW
2	2E4-034-01	DRAG WASHER RETAINER	29	2F5-445-01	ROLLER CLUTCH RETAINER
3	2W2-084-01	KEY WASHER	30	2Q2-021-01	SPRING
4	2W1-226-01	080-260 WASHER	31	2YZ-028-01	ONE-WAY CLUTCH BEARING ASSEMBLY
5	2W3-035-01	EARED WASHER	32	2A4-085-01	ONE-WAY CLUTCH INNER TUBE
6	2YT-454-06	SPOOL TOTAL ASSEMBLY	33	2Z1-035-07	917-5 BALL BEARING
7	2W2-085-01	KEY WASHER	34	2G2-169-01	PINION GEAR
8	2L3-018-01	CLICK LEAF SPRING	35	2E1-051-01	D30-080 SCREW
9	2F8-027-04	CLICK LEAF SPRING HOLDER	36	2B1-179-05	BODY
10	2W2-083-01	KEY WASHER	37	2Z1-023-07	814-4 BALL BEARING
11	2E3-003-01	ROTOR NUT	38	2G1-155-01	DRIVE GEAR
12	2M3-155-01	MAIN SHAFT	39	2W1-035-01	080-105 WASHER
13	2E1-036-01	B26-040 SCREW	40	2M2-025-01	OSCILLATING CAM
14	2R1-149-06	ROTOR	41	2G3-096-01	OSCILLATING GEAR
15	2Q3-118-01	BAIL SPRING	42	2M1-076-01	OSCILLATING SLIDER
16	2R4-209-01	BAIL TRIP COVER	43	2E2-014-01	F26M-060 SCREW
17	2E1-015-02	B26-060 SCREW	44	2B2-129-06	BODY COVER
18	2E2-094-01	B30M-090 SCREW	45	2E1-006-02	A30-130 SCREW
19	2R2-073-06	BAIL ARM	46	2YH-425-01	HANDLE TOTAL ASSEMBLY
20	2E1-014-01	B40-100 SCREW	47	2C3-042-01	HANDLE SCREW SLEEVE
21	2W1-258-01	030-060 WASHER	48	2H6-001-13	HANDLE SCREW CAP
22	2Z1-012-07	407-2.5 BALL BEARING	49	2A2-107-06	ANTI-REVERSE CAM
23	2R6-020-02	LINE ROLLER	50	2L5-010-01	ANTI-REVERSE CAM SPRING
24	2C1-120-01	COLLAR	51	2F5-444-01	REAR COVER
25	2YL-161-06	BAIL ASSEMBLY	52	2E1-065-01	B22-065 SCREW
26	2R5-185-01	BAIL TRIP LEVER	LZ5000	SPECIAL PARTS	
27	2R4-208-01	BAIL SPRING COVER	6	2YT-458-06	SPOOL TOTAL ASSEMBLY