


## SPINNING REEL

Please order by parts number, not key number  
Bitte, Best.-Nr. angeben (Nicht "key"-nr.)  
Veuillez indiquer le numero de la piece (Non "key" no.)

## GAA2500



KEY NO.	Parts No.	Parts name	KEY NO.	Parts No.	Parts name
1	012-AX1-01	DRAG KNOB	30	012-AX1-26	BALL BAERING COVER
2	012-AX1-02	SIX CORNER	31	012-AX1-27	BALL BEARING ( 071404 )
3	012-AX1-03	KEY WASHER	32	012-AX1-28	PINIOR GEAR BUSHING
4	012-AX1-04	DRAG WASHER	33	012-AX1-29	ONE WAY CLUTCH ASSY
5	012-AX1-05	EAR WASHER	34	012-AX1-30	PINIOR GEAR
6	012-AX1-06	SPOOL ASSY	35	012-AX1-31	HANDLE SCREW WASHER
7	012-AX1-07	CLICK GEAR SPRING	36	012-AX1-32	HANDLE SCREW
8	012-AX1-08	CLICK GEAR SPRING	37	012-AX1-33	BODY
9	012-AX1-09	MAIN SHAFT	38	012-AX1-34	ONE WAY CLUTCH SPRING
10	012-AX1-10	SIX CORNER SPRING	39	012-AX1-35	ANTI-REVERSE LEVEL SPRING
11	012-AX1-11	SCREW	40	012-AX1-36	ANTI-REVERSE LEVEL
12	012-AX1-12	ROTOR	41	012-AX1-37	ANTI-REVERSE BUTTON
13	012-AX1-13	BAIL ASSY SCREW	42	012-AX1-38	ANTI-REVERSE BUTTON SCREW
14	012-AX1-14	BAIL ARM	43	012-AX1-39	BALL BEARING ( 071103 )
15	012-AX1-15	BAIL ASSY SCREW	44	012-AX1-40	DRIVE GEAR
16	012-AX1-16	LINE ROLLER WASHER	45	012-AX1-41	DRIVE GEAR WASHER
17	012-AX1-17	LINE ROLLER	46	012-AX1-42	BALL BEARING ( 071404 )
18	012-AX1-18	BALL BEARING ( 08052.5 )	47	012-AX1-43	BODY COVER
19	012-AX1-19	BAIL ASSY SCREW	48	012-AX1-44	BODY COVER SCREW 1
20	012-AX1-20	ROTOR COVER SCREW	49	012-AX1-45	HANDLE ASSY
21	012-AX1-21	ROTOR COVER	50	012-AX1-46	BODY COVER SCREW 2
22	012-AX1-22	SPRING HOLDER	51	012-AX1-47	BODY CAP
23	012-AX1-23	YOKE	52	012-AX1-48	BODY CAP SCREW
24	012-AX1-24	BAIL ARM SUPPORT PIN	53	012-AX1-49	OSCILLATION GEAR
25	012-AX1-25	CLICK LEVEL	54	012-AX1-49	OSCILLATION GEAR SCREW
26	012-AX1-26	ROTOR COVER	55	012-AX1-49	SLIDER
27	012-AX1-27	ROTOR COVER SCREW	56	012-AX1-49	SLIDER FIX SCREW
28	012-AX1-28	SUPPORT PLATE SCREW	57	012-AX1-49	SLIDER COVER
29	012-AX1-29	PINIOR GEAR WASHER	58	012-AX1-49	SLIDER COVER SCREW