




SPINNING REEL

Please order by parts number, not key number
 Bitte, Best.-Nr. angeben (Nicht "key"-nr.)
 Veuillez indiquer le numero de la piece (Non "key" no.)

GAA4000



| KEY NO. | Parts No. | Parts name | KEY NO. | Parts No. | Parts name |
|---------|------------|-------------------------|---------|------------|---------------------------|
| 1 | 015-AX1-01 | DRAG KNOB | 29 | 015-AX1-29 | BALL BAERING COVER |
| 2 | 015-AX1-02 | SIX CORNER | 30 | 015-AX1-30 | BALL BEARING (081605)X1 |
| 3 | 015-AX1-03 | KEY WASHER(X2) | 31 | 015-AX1-31 | PINIOR GEAR BUSHING |
| 4 | 015-AX1-04 | DRAG WASHER(X3) | 32 | 015-AX1-32 | ONE WAY CLUTCH ASSY |
| 5 | 015-AX1-05 | EAR WASHER | 33 | 015-AX1-33 | PINIOR GEAR |
| 6 | 015-AX1-06 | SPOOL ASSY | 34 | 015-AX1-34 | HANDLE SCREW WASHER |
| 7 | 015-AX1-07 | CLICK GEAR SPRING | 35 | 015-AX1-35 | HANDLE SCREW |
| 8 | 015-AX1-08 | CLICK GEAR SPRING | 36 | 015-AX1-36 | BODY |
| 9 | 015-AX1-09 | MAIN SHAFT | 37 | 015-AX1-37 | ONE WAY CLUTCH SPRING |
| 10 | 015-AX1-10 | SIX CORNER SPRING | 38 | 015-AX1-38 | ANTI-REVERSE LEVEL SPRING |
| 11 | 015-AX1-11 | SCREW | 39 | 015-AX1-39 | ANTI-REVERSE LEVEL |
| 12 | 015-AX1-12 | ROTOR | 40 | 015-AX1-40 | ANTI-REVERSE BUTTON |
| 13 | 015-AX1-13 | BAIL ASSY SCREW | 41 | 015-AX1-41 | ANTI-REVERSE BUTTON SCREW |
| 14 | 015-AX1-14 | BAIL ARM | 42 | 015-AX1-42 | BALL BEARING |
| 15 | 015-AX1-15 | BAIL ASSY SCREW(X2) | 43 | 015-AX1-43 | DRIVE GEAR |
| 16 | 015-AX1-16 | LINE ROLLER WASHER | 44 | 015-AX1-44 | DRIVE GEAR WASHER |
| 17 | 015-AX1-17 | LINE ROLLER | 45 | 015-AX1-45 | BODY COVER |
| 18 | 015-AX1-18 | BALL BEARING | 46 | 015-AX1-46 | BODY COVER SCREW 1 (X3) |
| 19 | 015-AX1-19 | BAIL ASSY SCREW | 47 | 015-AX1-47 | HANDLE ASSY |
| 20 | 015-AX1-20 | ROTOR COVER SCREW | 48 | 015-AX1-48 | BODY COVER SCREW 2 (X2) |
| 21 | 015-AX1-21 | ROTOR COVER | 49 | 015-AX1-49 | BODY CAP |
| 22 | 015-AX1-22 | SPRING HOLDER | 50 | 015-AX1-50 | BODY CAP SCREW |
| 23 | 015-AX1-23 | YOKE | 51 | 015-AX1-51 | OSCILLATION GEAR |
| 24 | 015-AX1-24 | BAIL ARM SUPPORT PIN | 52 | 015-AX1-52 | OSCILLATION GEAR SCREW |
| 25 | 015-AX1-25 | CLICK LEVEL | 53 | 015-AX1-53 | SLIDER |
| 26 | 015-AX1-26 | ROTOR COVER | 54 | 015-AX1-54 | SLIDER FIX SCREW |
| 27 | 015-AX1-27 | ROTOR COVER SCREW | 55 | 015-AX1-55 | SLIDER COVER |
| 28 | 015-AX1-28 | SUPPORT PLATE SCREW(X3) | 56 | 015-AX1-56 | SLIDER COVER SCREW |