




## SPINNING REEL

Please order by parts number, not key number  
 Bitte, Best.-Nr. angeben (Nicht "key"-nr.)  
 Veuillez indiquer le numero de la piece (Non "key" no.)

## GAA5000



KEY NO.	Parts No.	Parts name	KEY NO.	Parts No.	Parts name
1	017-AX1-01	DRAG KNOB	29	017-AX1-29	BALL BAERING COVER
2	017-AX1-02	SIX CORNER	30	017-AX1-30	BALL BEARING ( 081605 )X1
3	017-AX1-03	KEY WASHER(X2)	31	017-AX1-31	PINIOR GEAR BUSHING
4	017-AX1-04	DRAG WASHER(X3)	32	017-AX1-32	ONE WAY CLUTCH ASSY
5	017-AX1-05	EAR WASHER	33	017-AX1-33	PINIOR GEAR
6	017-AX1-06	SPOOL ASSY	34	017-AX1-34	HANDLE SCREW WASHER
7	017-AX1-07	CLICK GEAR SPRING	35	017-AX1-35	HANDLE SCREW
8	017-AX1-08	CLICK GEAR SPRING	36	017-AX1-36	BODY
9	017-AX1-09	MAIN SHAFT	37	017-AX1-37	ONE WAY CLUTCH SPRING
10	017-AX1-10	SIX CORNER SPRING	38	017-AX1-38	ANTI-REVERSE LEVEL SPRING
11	017-AX1-11	SCREW	39	017-AX1-39	ANTI-REVERSE LEVEL
12	017-AX1-12	ROTOR	40	017-AX1-40	ANTI-REVERSE BUTTON
13	017-AX1-13	BAIL ASSY SCREW	41	017-AX1-41	ANTI-REVERSE BUTTON SCREW
14	017-AX1-14	BAIL ARM	42	017-AX1-42	BALL BEARING
15	017-AX1-15	BAIL ASSY SCREW(X2)	43	017-AX1-43	DRIVE GEAR
16	017-AX1-16	LINE ROLLER WASHER	44	017-AX1-44	DRIVE GEAR WASHER
17	017-AX1-17	LINE ROLLER	45	017-AX1-45	BODY COVER
18	017-AX1-18	BALL BEARING	46	017-AX1-46	BODY COVER SCREW 1 (X3)
19	017-AX1-19	BAIL ASSY SCREW	47	017-AX1-47	HANDLE ASSY
20	017-AX1-20	ROTOR COVER SCREW	48	017-AX1-48	BODY COVER SCREW 2 (X2)
21	017-AX1-21	ROTOR COVER	49	017-AX1-49	BODY CAP
22	017-AX1-22	SPRING HOLDER	50	017-AX1-50	BODY CAP SCREW
23	017-AX1-23	YOKE	51	017-AX1-51	OSCILLATION GEAR
24	017-AX1-24	BAIL ARM SUPPORT PIN	52	017-AX1-52	OSCILLATION GEAR SCREW
25	017-AX1-25	CLICK LEVEL	53	017-AX1-53	SLIDER
26	015-AX1-26	ROTOR COVER	54	017-AX1-54	SLIDER FIX SCREW
27	015-AX1-27	ROTOR COVER SCREW	55	017-AX1-55	SLIDER COVER
28	015-AX1-28	SUPPORT PLATE SCREW(X3)	56	017-AX1-56	SLIDER COVER SCREW