




BAIT CASTING REEL

TACTICA

KJ50H

(-10# / -8# / -6#)



Key NO.

Parts No.

Parts name

1	2E2-089-01	A26M-045 SCREW
2	2F6-043-02	ROTOR NUT HOLDING PLATE
3	2E3-075-01	HANDLE NUT
4	2YH-309-04	HANDLE TOTAL ASSEMBLY
5	2W2-058-01	KEY WASH
6	2E4-018-01	RETAINER
7	2F8-050-01	CLICK LEAF SPRING HOLDER
8	2L3-029-01	CLICK LEAF SPRING
9	2D4-008-04	STAR DRAG LEVER
10	2Q1-052-01	STAR DRAG SPRING
11	2E3-029-01	STAR DRAG NUT
12	2W1-020-01	081-130 WASHER
13	2L1-004-01	SPRING WASHER
14	2W1-035-05	080-105 WASHER
15	2Z1-024-05	812-2.5 BALL BEARING
16	2F5-409-02	RIGHT SIDE COVER
17	2E2-031-01	A26M-075 SCREW
18	2E3-077-01	CAST CONTROL NUT
19	2W5-026-01	SPACER
20	2W5-029-01	CAST CONTROL SPACER
21	2E4-019-01	BEARING RETAINER
22	2Z1-029-05	408-3 BALL BEARING
23	2E9-005-01	O RING
24	2YZ-026-01	ONE-WAY CLUTCH BEARING ASSEMBLY
25	2A4-073-01	ONE-WAY CLUTCH INNER TUBE
26	2W2-072-01	KEY WASHER
27	2W1-228-01	082-230 WASHER
28	2W3-036-01	EARED WASHER
29	2W2-073-01	KEY WASHER
30	2W1-227-01	125-250 WASHER
31	2G1-133-01	DRIVE GEAR
32	2W1-083-01	103-200 WASHER
33	2YM-093-01	DRIVE SHAFT ASSEMBLY
34	2G3-027-01	IDLE GEAR
35	2W1-075-01	051-100 WASHER
36	2E2-044-01	A20M-050 SCREW
37	2F6-036-01	DRIVE SHAFT RETAINER
38	2Z1-001-05	508-2.5 BALL BEARING
39	2W1-124-01	045-065 WASHER
40	2E5-006-01	E2.5 RETAINER
41	2YM-026-01	WORM SHAFT ASSEMBLY
42	2C1-055-01	SPACER
43	2W5-041-01	SPACER
44	2E2-050-01	A20M-035 SCREW

Key NO.

Parts No.

Parts name

45	2C2-059-01	WORM SHAFT BUSH A
46	2YR-071-01	LINE GUIDE ASSEMBLY
47	2M5-006-01	LINE GUIDE PIN
48	2W1-100-01	020-068 WASHER
49	2E3-028-01	LINE GUIDE NUT
50	2P4-007-01	OSCILLATING SLIDER PIN
51	2C4-009-01	LEVEL WIND GUARD
52	2C2-060-01	WORM SHAFT BUSH B
53	2B1-162-02	BODY
54	2E5-013-01	E3.0 RETAINER
55	2W1-079-01	040-070 WASHER
56	2YT-460-01	SPOOL TOTAL ASSEMBLY
57	2C4-026-01	CASTING BAR GUIDE B
58	2S3-030-01	CASTING BAR
59	2E2-030-02	F20M-050 SCREW
60	2C4-025-01	CASTING BAR GUIDE A
61	2Z1-010-05	812-3.5 BALL BEARING
62	2A2-095-01	CLUTCH CAM ASSEMBLY
63	2Q3-063-01	CLUTCH PAWL SPRING
64	2A4-036-01	CLUTCH PAWL
65	2F8-042-01	CLUTCH CAM RETAINER
66	2E2-068-02	F20M-065 SCREW
67	2A2-043-01	PINION YOKE
68	2Q1-031-01	YOKE SPRING
69	2G2-047-01	PINION GEAR
70	2F5-327-01	LOCKER NUT
71	2Q1-098-01	SPRING
72	2F7-008-06	COVER LOCKER
73	2W1-079-01	040-070 WASHER
74	2F5-424-02	LEFT SIDE COVER
75	2L3-040-01	CLICK LEAF SPRING
76	2YF-160-01	CENTRIFUGAL DRAG SET ASSEMBLY
77	2E1-068-01	F30-100 SCREW
78	2W5-079-04	CAST CONTROL SPACER
79	2W5-078-01	SPACER
80	2Z1-015-02	310-4 BALL BEARING
81	2E4-011-01	BEARING RETAINER
82	2D3-061-01	BUFFER
83	2C2-107-01	BRAKE COLLAR
84	2X3-004-02	WRECH
-8#	SPECIAL PARTS	
56	2YT-351-04	SPOOL TOTAL ASSEMBLY
-10#	SPECIAL PARTS	
56	2YT-426-04	SPOOL TOTAL ASSEMBLY