



| Parts No.  | Parts name           | Key NO. | Parts No.  | Parts name                      |
|------------|----------------------|---------|------------|---------------------------------|
| 2YD-111-03 | DRAG KNOB ASSEMBLY   | 31      | 2E1-050-01 | A20-060 SCREW                   |
| 2E4-008-01 | DRAG WASHER RETAINER | 32      | 2F5-510-01 | ROLLER CLUTCH RETAINER          |
| 2W2-042-01 | KEY WASHER           | 33      | 2Z1-019-05 | 612-4 BALL BEARING              |
| 2W1-159-02 | 045-152 WASHER       | 34      | 2M3-170-01 | MAIN SHAFT                      |
| 2YT-529-02 | SPOOL TOTAL ASSEMBLY | 35      | 2C1-138-01 | BUSHING                         |
| 2S4-019-01 | LINE STOPPER         | 36      | 2A4-092-01 | ONE-WAY CLUTCH INNER TUBE       |
| 2Q3-121-01 | SPRING               | 37      | 2YZ-032-01 | ONE-WAY CLUTCH BEARING ASSEMBLY |
| 2Q2-015-01 | CLICK PAWL SPRING    | 38      | 2Q2-024-01 | SPRING                          |
| 2E5-020-01 | E1.5 RETAINER        | 39      | 2G2-185-01 | PINION GEAR                     |
| 2L2-015-01 | CLICK PAWL           | 40      | 2B1-198-03 | BODY                            |
| 2W1-051-02 | 033-065 WASHER       | 41      | 2L5-025-01 | ANTI-REVERSE CAM SPRING         |
| 2F3-077-01 | CLICK GEAR           | 42      | 2A2-120-01 | ANTI-REVERSE CAM                |
| 2E3-062-01 | ROTOR NUT            | 43      | 2C3-042-01 | HANDLE SCREW SLEEVE             |
| 2E1-056-01 | X20-035 SCREW        | 44      | 2H6-016-02 | HANDLE SCREW CAP                |
| 2C3-027-01 | ROTOR NUT RETAINER   | 45      | 2Z1-011-05 | 711-2.5 BALL BEARING            |
| 2R1-154-03 | ROTOR                | 46      | 2G1-165-01 | DRIVE GEAR                      |
| 2R5-197-01 | BAIL PAWL            | 47      | 2W1-019-00 | 071-103 WASHER                  |
| 2R5-177-01 | BAIL TRIP LEVER      | 48      | 2Z1-011-05 | 711-2.5 BALL BEARING            |
| 2W1-199-01 | 015-027 WASHER       | 49      | 2B2-142-03 | BODY COVER                      |
| 2Q3-120-01 | BAIL SPRING          | 50      | 2E1-045-01 | A26-080 SCREW                   |
| 2R4-218-02 | BAIL SPRING COVER    | 51      | 2E1-060-01 | A26-060 SCREW                   |
| 2E1-020-02 | B22-055 SCREW        | 52      | 2YH-263-03 | HANDLE TOTAL ASSEMBLY           |
| 2E2-018-01 | B30M-080 SCREW       | 53      | 2G3-101-01 | OSCILLATING GEAR                |
| 2R2-075-02 | BAIL ARM             | 54      | 2M1-083-01 | OSCILLATING SILDER              |
| 2E1-024-01 | b30-060 SCREW        | 55      | 2E2-103-01 | F20M-030 SCREW                  |
| 2C1-056-01 | LINE ROLLER COLLAR   | 56      | 2A1-038-02 | ANTI-REVERSE LEVER              |
| 2Z1-012-05 | 407-2.5 BALL BEARING | 57      | 2E2-099-01 | B20M-050 SCREW                  |
| 2R6-012-01 | LINE ROLLER          | 58      | 2F5-483-02 | REAR COVER                      |
| 2C2-032-01 | LINE ROLLER BUSH     | 59      | 2E1-071-01 | B26-040 SCREW                   |
| 2YL-166-01 | BAIL ASSEMBLY        |         |            |                                 |