




# SALTWATER REEL WRECK SERIES WR348



Key NO.	Parts No.	Parts name	Key NO.	Parts No.	Parts name
1	2E2-006-01	B26M-050 SCREW	34	2M3-110-01	DRIVE SHAFT
2	2F6-043-04	ROTOR NUT HOLDING PLATE	35	2A3-034-01	RATCHET
3	2E3-027-01	HANDLE NUT	36	2W1-169-01	061-120 WASHER
4	2YH-195-03	HANDLE TOTAL ASSEMBLY	37	2E5-028-01	E4.0 RETAINER
5	2W2-044-01	KEY WASHER	38	2G2-113-01	PINION GEAR
6	2YD-046-01	STAR DRAG LEVER ASSY	39	2Q1-080-01	YOKE SPRING
7	2L3-025-01	CLICK LEAF SPRING	40	2A2-068-01	PINION YOKE
8	2W2-043-01	KEY WASHER	41	2F6-067-01	YOKE PLATE
9	2F8-060-01	CLICK LEAF SPRING HOLDER	42	2P1-036-01	ANTI-REVERSE PAWL PIN
10	2L1-007-01	SPRING WASHER	43	2A4-055-01	ANTI-REVERSE PAWL
11	2Z1-023-05	814-4 BALL BEARING	44	2Q2-009-01	CLICK PAWL SPRING
12	2E3-048-01	CAST CONTROL NUT	45	2F6-094-01	SPRING RETAIN
13	2W5-029-01	CAST CONTROL SPACER	46	2E1-032-01	A20-050 SCREW
14	2E9-005-01	O RING	47	2YB-196-03	BODY ASSEMBLY
15	2S3-023-03	CLUTCH LEVER	48	2YS-147-01	SPOOL ASSEMBLY
16	2E1-009-01	A30-100 SCREW	49	2Z1-035-05	917-5 BALL BEARING
17	2F5-305-03	RIGHT SIDE COVER	50	2W1-097-01	059-100 WASHER
18	2Q3-099-01	CLUTCH SPRING	51	2F3-052-01	CLICK GEAR
19	2A2-069-01	CLUTCH CAM	52	2G3-049-01	SPOOL GEAR
20	2E1-014-01	B40-100 SCREW	53	2E5-006-01	E2.5 RETAINER
21	2Z2-017-01	BUSHING	54	2E1-020-02	B22-055 SCREW
22	2F8-072-01	ANTI-REVERSE RATCHET SET	55	2F6-098-01	RETAINER
23	2YZ-013-01	ONE-WAY CLUTCH BEARING ASSEMBLY	56	2W5-015-01	CAST CONTROL SPACER
24	2F6-068-01	HOLDING PLATE	57	2F5-304-03	LEFT SIDE COVER
25	2E1-036-01	B26-040 SCREW	58	2W5-040-01	CLICK SWITCH WASHER
26	2A4-026-01	ONE-WAY CLUTCH INNER TUBE	59	2F7-006-01	CLICK SWITCH
27	2W2-046-01	KEY WASHER	60	2E3-061-01	SIDEPLATE HOLDING NUT
28	2W1-170-01	082-300 WASHER	61	2F4-019-01	CLICK PAWL
29	2W3-025-01	EARED WASHER	62	2F2-020-01	CLICK SPRING
30	2W2-045-01	KEY WASHER	63	2E1-048-01	B22-080 SCREW
31	2G1-096-01	ORIVE GEAR	64	2F6-100-01	MAGNET RETAIN
32	2W1-192-01	090-340 WASHER	65	2D3-030-01	MAGNET
33	2W2-059-01	KEY WASHER	66	2F6-101-01	MAGNET SET PLATE